



EN

welding torch

MT221-301G F2

MT221-301G F3

MT221-401G (ON SRA-Kit)

PM221-401G (ON SRA-Kit)

099-510050-EW501

Observe additional system documents!

18.10.2023

**Register now
and benefit!
Jetzt Registrieren
und Profitieren!**

www.ewm-group.com



General instructions

WARNING



Read the operating instructions!

The operating instructions provide an introduction to the safe use of the products.

- Read and observe the operating instructions for all system components, especially the safety instructions and warning notices!
- Observe the accident prevention regulations and any regional regulations!
- The operating instructions must be kept at the location where the machine is operated.
- Safety and warning labels on the machine indicate any possible risks. Keep these labels clean and legible at all times.
- The machine has been constructed to state-of-the-art standards in line with any applicable regulations and industrial standards. Only trained personnel may operate, service and repair the machine.
- Technical changes due to further development in machine technology may lead to a differing welding behaviour.

In the event of queries on installation, commissioning, operation or special conditions at the installation site, or on usage, please contact your sales partner or our customer service department on +49 2680 181-0.

A list of authorised sales partners can be found at www.ewm-group.com/en/specialist-dealers.

Liability relating to the operation of this equipment is restricted solely to the function of the equipment. No other form of liability, regardless of type, shall be accepted. This exclusion of liability shall be deemed accepted by the user on commissioning the equipment.

The manufacturer is unable to monitor whether or not these instructions or the conditions and methods are observed during installation, operation, usage and maintenance of the equipment.

An incorrectly performed installation can result in material damage and injure persons as a result. For this reason, we do not accept any responsibility or liability for losses, damages or costs arising from incorrect installation, improper operation or incorrect usage and maintenance or any actions connected to this in any way.

© EWM GmbH

Dr. Günter-Henle-Strasse 8

56271 Mündersbach Germany

Tel.: +49 2680 181-0, Fax: -244

Email: info@ewm-group.com

www.ewm-group.com

The copyright to this document remains the property of the manufacturer.

Copying, including extracts, only permitted with written approval.

The content of this document has been prepared and reviewed with all reasonable care. The information provided is subject to change; errors excepted.

Data security

The user is responsible for backing up data of all changes from the factory setting. The user is liable for erased personal settings. The manufacturer does not assume any liability for this.

1	Contents	3
1	Contents	3
2	For your safety	5
2.1	Notes on using these operating instructions	5
2.2	Explanation of icons	6
2.3	Safety instructions	7
2.4	Transport and installation	10
3	Intended use	12
3.1	Applications	12
3.2	Documents which also apply	12
3.2.1	Warranty	12
3.2.2	Declaration of Conformity	12
3.2.3	Service documents (spare parts)	12
3.2.4	Part of the complete documentation	13
4	Product description – quick reference	14
4.1	Product variants	14
4.2	Welding fume extractor	14
4.2.1	MT 221-, MT 301G F2	14
4.2.2	MT221-, MT301G F3	15
4.2.3	MT- / PM 221G, - 301G,- 401G with conversion kit ON SRA-Kit PM / MT	16
5	Design and function	17
5.1	General	17
5.2	Scope of delivery	18
5.3	Transport and installation	18
5.3.1	Ambient conditions	18
5.4	Configure welding torch	18
5.4.1	Using the torch key	19
5.4.1.1	Contact tip	19
5.4.1.2	Contact tip holder	20
5.5	Equipment recommendations	21
5.6	Adapting the Euro torch connection on the device	23
5.6.1	Liner	23
5.6.2	Guide spiral	23
5.6.3	Assemble the wire guide	23
5.6.3.1	Liner	24
5.6.4	Guide spiral	27
5.7	Setting the welding smoke flow rate	30
5.7.1	Test preparation	30
5.7.2	Checking the flow rate of the welding fumes	31
5.8	Function specification	31
5.8.1	General	31
6	Maintenance, care and disposal	32
6.1	General	32
6.1.1	Identifying damage or worn components	32
6.1.2	Maintenance and care before each use	34
6.1.3	Regular maintenance	35
6.2	Disposing of equipment	36
7	Rectifying faults	37
7.1	Checklist for rectifying faults	37
8	Technical data	39
8.1	MT 221-, MT 301G F2	39
8.2	MT 221-, MT 301G F3	40
8.3	MT- / PM 221G, - 301G,- 401G with conversion kit ON SRA-Kit PM / MT	41
8.3.1	Explanation of terms	42
9	Accessories	43
9.1	List of tools	43
9.2	Dimensions	43
9.2.1	Spare parts for airflow meters	43

9.3	Adapter for welding fume extractor torch F3	43
9.4	Extraction hose	43
9.5	Replacement parts set	44
9.6	Option.....	44
10	Replaceable parts.....	45
10.1	MT221 G F2, -F3.....	45
10.2	MT301G F2, -F3.....	47
10.3	MT- / PM 221G (ON SRA-Kit PM / MT 221G / 301W).....	49
10.4	MT- / PM 301G (ON SRA-Kit PM / MT 301G).....	51
10.5	MT- / PM 401G (ON SRA-Kit PM / MT 401G).....	53
11	Service documents	55
11.1	Circuit diagrams	55
12	Appendix.....	56
12.1	Altitude alignment.....	56
12.2	Searching for a dealer.....	57

2 For your safety

2.1 Notes on using these operating instructions

DANGER

Working or operating procedures which must be closely observed to prevent imminent serious and even fatal injuries.

- Safety notes include the "DANGER" keyword in the heading with a general warning symbol.
- The hazard is also highlighted using a symbol on the edge of the page.

WARNING

Working or operating procedures which must be closely observed to prevent serious and even fatal injuries.

- Safety notes include the "WARNING" keyword in the heading with a general warning symbol.
- The hazard is also highlighted using a symbol in the page margin.

CAUTION

Working or operating procedures which must be closely observed to prevent possible minor personal injury.

- The safety information includes the "CAUTION" keyword in its heading with a general warning symbol.
- The risk is explained using a symbol on the edge of the page.



Technical aspects which the user must observe to avoid material or equipment damage.

Instructions and lists detailing step-by-step actions for given situations can be recognised via bullet points, e.g.:

- Insert the welding current lead socket into the relevant socket and lock.

2.2 Explanation of icons

Symbol	Description	Symbol	Description
	Indicates technical aspects which the user must observe.		Activate and release / Tap / Tip
	Switch off machine		Release
	Switch on machine		Press and hold
	Incorrect / Invalid		Switch
	Correct / Valid		Turn
	Input		Numerical value – adjustable
	Navigation		Signal light lights up in green
	Output		Signal light flashes green
	Time representation (e.g.: wait 4 s / actuate)		Signal light lights up in red
	Interruption in the menu display (other setting options possible)		Signal light flashes red
	Tool not required/do not use		Signal light lights up in blue
	Tool required/use		Signal light flashes blue

2.3 Safety instructions

WARNING



Risk of accidents due to non-compliance with the safety instructions!
Non-compliance with the safety instructions can be fatal!

- Carefully read the safety instructions in this manual!
- Observe the accident prevention regulations and any regional regulations!
- Inform persons in the working area that they must comply with the regulations!



Risk of injury from electrical voltage!

Voltages can cause potentially fatal electric shocks and burns on contact. Even low voltages can cause a shock and lead to accidents.

- Never touch live components such as welding current sockets or stick, tungsten or wire electrodes!
- Always place torches and electrode holders on an insulated surface!
- Wear the full personal protective equipment (depending on the application)!
- The machine may only be opened by qualified personnel!
- The device must not be used to defrost pipes!



Hazard when interconnecting multiple power sources!

If a number of power sources are to be connected in parallel or in series, only a technical specialist may interconnect the sources as per standard IEC 60974-9:2010: Installation and use and German Accident Prevention Regulation BVG D1 (formerly VBG 15) or country-specific regulations.

Before commencing arc welding, a test must verify that the equipment cannot exceed the maximum permitted open circuit voltage.

- Only qualified personnel may connect the machine.
- When taking individual power sources out of operation, all mains and welding current leads must be safely disconnected from the welding system as a whole. (Hazard due to reverse polarity voltage!)
- Do not interconnect welding machines with pole reversing switch (PWS series) or machines for AC welding since a minor error in operation can cause the welding voltages to be combined, which is not permitted.



Risk of injury due to radiation or heat!

Arc radiation can lead to skin and eye injuries.

Contact with hot workpieces and sparks can lead to burns.

- Use hand shield or welding helmet with the appropriate safety level (depends on the application).
- Wear dry protective clothing (e.g. hand shield, gloves, etc.) in accordance with the applicable regulations of your country.
- Persons who are not directly involved should be protected with a welding curtain or suitable safety screen against radiation and the risk of blinding!

WARNING



Risk of injury due to improper clothing!

During arc welding, radiation, heat and voltage are sources of risk that cannot be avoided. The user has to be equipped with the complete personal protective equipment at all times. The protective equipment has to include:

- Respiratory protection against hazardous substances and mixtures (fumes and vapours); otherwise implement suitable measures such as extraction facilities.
- Welding helmet with proper protection against ionizing radiation (IR and UV radiation) and heat.
- Dry welding clothing (shoes, gloves and body protection) to protect against warm environments with conditions comparable to ambient temperatures of 100 °C or higher and arcing and work on live components.
- Hearing protection against harming noise.



Explosion risk!

Apparently harmless substances in closed containers may generate excessive pressure when heated.

- Move containers with inflammable or explosive liquids away from the working area!
- Never heat explosive liquids, dusts or gases by welding or cutting!



Fire hazard!

Due to the high temperatures, sparks, glowing parts and hot slag that occur during welding, there is a risk of flames.

- Be watchful of potential sources of fire in the working area!
- Do not carry any easily inflammable objects, e.g. matches or lighters.
- Ensure suitable fire extinguishers are available in the working area!
- Thoroughly remove any residue of flammable materials from the workpiece prior to starting to weld.
- Only further process workpieces after they have cooled down. Do not allow them to contact any flammable materials!

⚠ CAUTION**Smoke and gases!**

Smoke and gases may lead to shortness of breath and poisoning! The ultraviolet radiation of the arc may also convert solvent vapours (chlorinated hydrocarbon) into poisonous phosgene.

- Ensure sufficient fresh air!
- Keep solvent vapours away from the arc beam field!
- Wear suitable respiratory protection if necessary!
- To prevent the formation of phosgene, residues of chlorinated solvents on workpieces must first be neutralised using appropriate measures.

**Noise exposure!**

Noise exceeding 70 dBA can cause permanent hearing damage!

- Wear suitable ear protection!
- Persons located within the working area must wear suitable ear protection!



According to IEC 60974-10, welding machines are divided into two classes of electromagnetic compatibility (the EMC class can be found in the Technical data) > see 8 chapter:



Class A machines are not intended for use in residential areas where the power supply comes from the low-voltage public mains network. When ensuring the electromagnetic compatibility of class A machines, difficulties can arise in these areas due to interference not only in the supply lines but also in the form of radiated interference.



Class B machines fulfil the EMC requirements in industrial as well as residential areas, including residential areas connected to the low-voltage public mains network.

Setting up and operating

When operating arc welding systems, in some cases, electro-magnetic interference can occur although all of the welding machines comply with the emission limits specified in the standard. The user is responsible for any interference caused by welding.

In order to **evaluate** any possible problems with electromagnetic compatibility in the surrounding area, the user must consider the following: (see also EN 60974-10 Appendix A)

- Mains, control, signal and telecommunication lines
- Radios and televisions
- Computers and other control systems
- Safety equipment
- The health of neighbouring persons, especially if they have a pacemaker or wear a hearing aid
- Calibration and measuring equipment
- The immunity to interference of other equipment in the surrounding area
- The time of day at which the welding work must be carried out

Recommendations for reducing interference emission

- Mains connection, e.g. additional mains filter or shielding with a metal tube
- Maintenance of the arc welding system
- Welding leads should be as short as possible and run closely together along the ground
- Potential equalization
- Earthing of the workpiece. In cases where it is not possible to earth the workpiece directly, it should be connected by means of suitable capacitors.
- Shielding from other equipment in the surrounding area or the entire welding system

**Electromagnetic fields!**

The power source can create electrical or electromagnetic fields that may impair the function of electronic systems such as EDP and CNC devices, telecommunication, power and signal lines as well as pacemakers and defibrillators.



- Follow the maintenance instructions > see 6 chapter!
- Unwind the welding leads completely!
- Shield radiation-sensitive equipment or facilities appropriately!
- The function of pacemakers may be impaired (seek medical advice if necessary).

CAUTION



Obligations of the operator!

The respective national directives and laws must be complied with when operating the machine!

- Implementation of national legislation relating to framework directive 89/391/EEC on the introduction of measures to encourage improvements in the safety and health of workers at work and associated individual guidelines.
- In particular, directive 89/655/EEC concerning the minimum safety and health requirements for the use of work equipment by workers at work.
- The regulations applicable to occupational safety and accident prevention in the country concerned.
- Setting up and operating the machine as per IEC 60974.-9.
- Brief the user on safety-conscious work practices on a regular basis.
- Regularly inspect the machine as per IEC 60974.-4.



The manufacturer's warranty becomes void if non-genuine parts are used!

- ***Only use system components and options (power sources, welding torches, electrode holders, remote controls, spare parts and replacement parts, etc.) from our range of products!***
- ***Only insert and lock accessory components into the relevant connection socket when the machine is switched off.***

Requirements for connection to the public mains network

High-performance machines can influence the mains quality by taking current from the mains network. For some types of machines, connection restrictions or requirements relating to the maximum possible line impedance or the necessary minimum supply capacity at the interface with the public network (Point of Common Coupling, PCC) can therefore apply. In this respect, attention is also drawn to the machines' technical data. In this case, it is the responsibility of the operator, where necessary in consultation with the mains network operator, to ensure that the machine can be connected.

2.4 Transport and installation

WARNING



Risk of injury due to improper handling of shielding gas cylinders!

Improper handling and insufficient securing of shielding gas cylinders can cause serious injuries!

- Observe the instructions from the gas manufacturer and any relevant regulations concerning the use of compressed air!
- Do not attach any element to the shielding gas cylinder valve!
- Prevent the shielding gas cylinder from heating up.

⚠ CAUTION**Risk of accidents due to supply lines!**

During transport, attached supply lines (mains leads, control cables, etc.) can cause risks, e.g. by causing connected machines to tip over and injure persons!

- Disconnect all supply lines before transport!

**Risk of tipping!**

There is a risk of the machine tipping over and injuring persons or being damaged itself during movement and set up. Tilt resistance is guaranteed up to an angle of 10° (according to IEC 60974-1).

- Set up and transport the machine on level, solid ground.
- Secure add-on parts using suitable equipment.

**Risk of accidents due to incorrectly installed leads!**

Incorrectly installed leads (mains, control and welding leads or intermediate hose packages) can present a tripping hazard.

- Lay the supply lines flat on the floor (avoid loops).
- Avoid laying the leads on passage ways.

**Risk of injury from heated coolant and its connections!**

The coolant used and its connection or connection points can heat up significantly during operation (water-cooled version). When opening the coolant circuit, escaping coolant may cause scalding.

- Open the coolant circuit only when the power source or cooling unit is switched off!
- Wear proper protective equipment (protective gloves)!
- Seal open connections of the hose leads with suitable plugs.



The units are designed for operation in an upright position!

Operation in non-permissible positions can cause equipment damage.

- ***Only transport and operate in an upright position!***



Accessory components and the power source itself can be damaged by incorrect connection!

- ***Only insert and lock accessory components into the relevant connection socket when the machine is switched off.***
- ***Comprehensive descriptions can be found in the operating instructions for the relevant accessory components.***
- ***Accessory components are detected automatically after the power source is switched on.***



Protective dust caps protect the connection sockets and therefore the machine against dirt and damage.

- ***The protective dust cap must be fitted if there is no accessory component being operated on that connection.***
- ***The cap must be replaced if faulty or if lost!***

3 Intended use

WARNING



Hazards due to improper usage!

The machine has been constructed to the state of the art and any regulations and standards applicable for use in industry and trade. It may only be used for the welding procedures indicated at the rating plate. Hazards may arise for persons, animals and material objects if the equipment is not used correctly. No liability is accepted for any damages arising from improper usage!

- The equipment must only be used in line with its designated purpose and by trained or expert personnel!
- Do not improperly modify or convert the equipment!

3.1 Applications

Welding fume extractor torch for arc welding machines for GMAW.

3.2 Documents which also apply

3.2.1 Warranty

For more information refer to the "Warranty registration" brochure supplied and our information regarding warranty, maintenance and testing at www.ewm-group.com!

3.2.2 Declaration of Conformity



This product corresponds in its design and construction to the EU directives listed in the declaration. The product comes with a relevant declaration of conformity in the original.

The manufacturer recommends carrying out the safety inspection according to national and international standards and guidelines every 12 months (from commissioning).

3.2.3 Service documents (spare parts)

WARNING



No improper repairs and modifications!

To prevent injuries and damage to the machine, only competent personnel (authorised service personnel) are allowed to repair or modify the machine.

Unauthorised manipulations will invalidate the warranty!

- Instruct competent personnel (authorised service personnel) to repair the machine.

Spare parts can be obtained from the relevant authorised dealer.

3.2.4 Part of the complete documentation

This document is part of the complete documentation and valid only in combination with all other parts of these instructions! Read and observe the operating instructions for all system components, especially the safety instructions!

The illustration shows a general example of a welding system.




Figure 3-1

Item	Documentation
A.1	Wire feeder
A.2	Options conversion instructions
A.3	Power source
A.4	Cooling unit, voltage converter, toolbox, etc.
A.5	Extraction and filter system
A.6	Transport cart
A.7	Welding torch
A.8	Remote control
A.9	Control
A	Complete documentation

4 Product description – quick reference

4.1 Product variants

Version	Functions	Performance class
G	Gas-cooled	MT221, MT301, MT401 PM201, PM301, PM401
F2, F3	Welding fume extractor The welding torch is designed to extract welding fumes and equipped with a ball joint.	MT201, MT301

4.2 Welding fume extractor

4.2.1 MT 221-, MT 301G F2




Figure 4-1

Item	Symbol	Description
1		Bypass slider, extraction capacity
2		Extraction nozzle
3		Gas nozzle
4		Torch trigger
5		Welding torch hose package
6		Connection, extraction unit Connect to extraction device or central extraction unit Ø = 42.5 mm
7		Euro central connection
8		Ball joint
9		Grip plate

4.2.2 MT221-, MT301G F3





Figure 4-2

Item	Symbol	Description
1		Grip plate
2		Bypass slider, extraction capacity
3		Extraction nozzle
4		Gas nozzle
5		Welding torch hose package
6		Connection - extraction unit - Ø = 63 mm Connection to the extraction unit or the central extraction (corresponding adapters > see 9 chapter)
7		Euro central connection
8		Torch trigger
9		Ball joint
10		Torch hose package With leather mask (2 meters as standard)

4.2.3 MT- / PM 221G, - 301G,- 401G with conversion kit ON SRA-Kit PM / MT





Figure 4-3

Item	Symbol	Description
1		Bypass slider, extraction capacity
2		Extraction nozzle
3		Gas nozzle
4		Welding torch hose package
5		Extraction hose
6		Connection, extraction unit
7		Euro central connection
8		Grip plate
9		Torch trigger

5 Design and function

5.1 General

WARNING



Risk of burns and electric shock on the welding torch!

Welding torch (torch neck or torch head) and coolant (water-cooled version) heat up strongly during the welding process. During assembly work, you may come into touch with electrical voltage or hot components.



- Wear proper protective equipment!
- Switch off the power source or torch cooling and allow the welding torch to cool!



Risk of injury from electrical voltage!

Contact with live parts, e.g. power connections, can be fatal!

- Observe the safety information on the first pages of the operating instructions!
- Commissioning must be carried out by persons who are specifically trained in handling power sources!
- Connect connection or power cables while the machine is switched off!

CAUTION



Risk of injury due to moving parts!

The wire feeders are equipped with moving parts, which can trap hands, hair, clothing or tools and thus injure persons!

- Do not reach into rotating or moving parts or drive components!
- Keep casing covers or protective caps closed during operation!



Risk of injury due to welding wire escaping in an unpredictable manner!

Welding wire can be conveyed at very high speeds and, if conveyed incorrectly, may escape in an uncontrolled manner and injure persons!

- Before mains connection, set up the complete wire guide system from the wire spool to the welding torch!
- Check wire guide at regular intervals!
- Keep all casing covers or protective caps closed during operation!

 **To prevent damage to the fume extraction torch, never operate it without the extraction nozzle.**

 **Accessory components and the power source itself can be damaged by incorrect connection!**

- **Only insert and lock accessory components into the relevant connection socket when the machine is switched off.**
- **Comprehensive descriptions can be found in the operating instructions for the relevant accessory components.**
- **Accessory components are detected automatically after the power source is switched on.**


 **Protective dust caps protect the connection sockets and therefore the machine against dirt and damage.**


- **The protective dust cap must be fitted if there is no accessory component being operated on that connection.**
- **The cap must be replaced if faulty or if lost!**

 **Machine damage due to incompletely assembled welding torch!**

Incomplete assembly may destroy the welding torch.

- **Always assemble the welding torch completely.**

 **After each opening of the welding torch, using the "gas test" "gas flush" function and increased flow rates, remove moisture, atmospheric oxygen and any impurities from the welding torch.**

 **Do not twist the hose package to no end in one direction so as to prevent damage to the fume extraction torch and the torch hose package. It is necessary to untwist the hose package regularly**

5.2 Scope of delivery

The delivery is checked and packaged carefully before dispatch, however it is not possible to exclude the possibility of damage during transit.

Receiving inspection

- Check that the delivery is complete using the delivery note!

In the event of damage to the packaging

- Check the delivery for damage (visual inspection)!

In the event of complaints

If the delivery has been damaged during transport:

- Please contact the last haulier immediately!
- Keep the packaging (for possible checking by the haulier or for the return shipment).

Packaging for returns

If possible, please use the original packaging and the original packaging material. If you have any queries on packaging and protection during transport, please contact your supplier.

5.3 Transport and installation

⚠ CAUTION



Risk of accidents due to supply lines!

During transport, attached supply lines (mains leads, control cables, etc.) can cause risks, e.g. by causing connected machines to tip over and injure persons!

- Disconnect all supply lines before transport!

5.3.1 Ambient conditions



Equipment damage due to contamination!

Unusually high amounts of dust, acids, corrosive gases or substances can damage the machine (observe maintenance intervals > see 6.1.2 chapter).

- **Avoid large amounts of smoke, steam, oily fumes, grinding dust and corrosive ambient air!**

In operation

Temperature range of the ambient air:

- -10 °C to +40 °C (-13 F to 104 F) ^[1]

Relative humidity:

- up to 50 % at 40 °C (104 F)
- up to 90 % at 20 °C (68 F)

Transport and storage

Storage in a closed area, temperature range of the ambient air:

- -25 °C to +55 °C (-13 F to 131 F) ^[1]

Relative humidity

- up to 90 % at 20 °C (68 F)

^[1] Ambient temperature dependent on coolant! Observe the coolant temperature range of the torch cooling

5.4 Configure welding torch

⚠ WARNING



Risk of burns and electric shock on the welding torch!

Welding torch (torch neck or torch head) and coolant (water-cooled version) heat up strongly during the welding process. During assembly work, you may come into touch with electrical voltage or hot components.



- Wear proper protective equipment!
- Switch off the power source or torch cooling and allow the welding torch to cool!

Switch off the extraction system.




Figure 5-1

Item	Symbol	Description
1		Extraction nozzle
2		Torch key > see 9 chapter
3		Grip plate
4		Gas distributor
5		Contact tip holder
6		Contact tip
7		Gas nozzle

- Loosen the extraction nozzle by hand.
- Unscrew the gas nozzle anti-clockwise by hand.
- Loosen the contact tip and contact tip holder with the torch key > see 5.4.1 chapter.
- Unscrew the gas diffuser by hand.



Comply with the permissible tightening torques to prevent damage to the torch and ensure correct attachment and contact tip contact > see 8 chapter!

- Assemble by following these steps in the reverse order

5.4.1 Using the torch key



To prevent torch damage, carried out the assembly in a clockwise direction and disassembly in an anti-clockwise direction.

5.4.1.1 Contact tip

The illustration serves as an example only.




Figure 5-2

- When assembling and disassembling the contact tip, use the corresponding slot weld of the torch key.

5.4.1.2 Contact tip holder

The illustration serves as an example only.




Figure 5-3

- When assembling and disassembling the contact tip holder, use the appropriate hexagon on the torch key.

5.5 Equipment recommendations




Figure 5-4

	Material	Design of contact tip (A)	Equipment side (B)	Wire feed rolls (C)	Capillary tube ⑨ / guide tube ⑩ (D)
DWire electrodes	Low-alloy	① CT CuCrZr	⑤	⑦ V-groove	⑨
	medium-alloy	① CT CuCrZr	⑤	⑦ V-groove	⑩
	Hardfacing	① CT CuCrZr	⑤	⑦ V-groove	⑩
	High-alloy	① CT CuCrZr	⑤	⑦ V-groove	⑩
	Aluminium	② CTAL E-Cu	④	⑥ U-groove	⑩
	Aluminium (AC)	③ CT ZWK CuCrZr	④	⑥ U-groove	⑩
	Copper alloy	① CT CuCrZr	⑤	⑦ V-groove	⑩
Flux cored wire electrode	Low-alloy	① CT CuCrZr	⑤	⑧ V-groove knurled	⑨
	High-alloy	① CT CuCrZr	⑤	⑧ V-groove knurled	⑩

	Material	Ø Wire	Ø Wire guide	Liner	Length of brass liner
Wire electrodes	Low-alloy	0.8	1.5 x 4.0	Steel liner	
		1.0	1.5 x 4.0		
		1.2	2.0 x 4.0		
		1.6	2.4 x 4.5		
	medium-alloy	0.8	1.5 x 4.0	Combined liner	200 mm
		1.0	1.5 x 4.0		
		1.2	2.0 x 4.0		
		1.6	2.3 x 4.7		
	Hardfacing	0.8	1.5 x 4.0	Combined liner	200 mm
		1.0	1.5 x 4.0		
		1.2	2.0 x 4.0		
		1.6	2.3 x 4.7		
	High-alloy	0.8	1.5 x 4.0	Combined liner	200 mm
		1.0	1.5 x 4.0		
		1.2	2.0 x 4.0		
		1.6	2.3 x 4.7		
	Aluminium	0.8	1.5 x 4.0	Combined liner	30 mm
		1.0	1.5 x 4.0		
		1.2	2.0 x 4.0		
		1.6	2.3 x 4.7		
Aluminium AC welding	0.8	1.5 x 4.0	Combined liner	100 mm	
	1.0	1.5 x 4.0			
	1.2	2.0 x 4.0			
	1.6	2.3 x 4.7			
Copper alloy	0.8	1.5 x 4.0	Combined liner	200 mm	
	1.0	1.5 x 4.0			
	1.2	2.0 x 4.0			
	1.6	2.3 x 4.7			
Flux cored wire electrode	Low-alloy	0.8	1.5 x 4.0	Steel liner	
		1.0	1.5 x 4.0		
		1.2	2.0 x 4.0		
		1.6	2.4 x 4.5		
	High-alloy	0.8	1.5 x 4.0	Combined liner	200 mm
		1.0	1.5 x 4.0		
		1.2	2.0 x 4.0		
		1.6	2.3 x 4.7		

5.6 Adapting the Euro torch connection on the device

On delivery, the Euro torch connector on the wire feeder is fitted with a capillary tube for welding torches with a steel liner!

5.6.1 Liner

- Push forward the capillary tube on the wire feed side in the direction of the Euro torch connector and remove it there.
- Insert the guide tube from the Euro torch connection.
- Insert the welding torch connector with the excessively long liner carefully into the Euro torch connector and screw hand-tight using the crown nut.
- Cut off the liner using a special cutter or sharp knife just before the wire feed roller, making sure not to pinch it.
- Loosen the welding torch connector and remove.
- Cleanly trim the separated end of the liner!

5.6.2 Guide spiral

- Check the Euro torch connector for correct seating of the capillary tube!

5.6.3 Assemble the wire guide

Use the correct wire guide from spool to molten pool!

The wire guide has to be adjusted to the wire electrode type and diameter in order to achieve good welding results!

- Equip the wire feeder according to wire electrode type and diameter!
- Refer to the manufacturer instructions for the right wire feed unit equipment. Refer to Annex 1 in these operating instructions for the right EWM machine equipment > see *10 chapter*.
- Use a steel liner inside the torch hose package to guide hard, unalloyed wire electrodes (steel)!
- Use a plastic liner inside the torch hose package to guide soft or alloyed wire electrodes!

Equipment side for steel liner or liner > see 5.5 chapter.

5.6.3.1 Liner

Observe permissible torque > see 8 chapter!

The distance between the plastic liner and drive rollers should be as short as possible.

Use only sharp, stable knives or special tongs for cutting to ensure that the plastic liner does not become misshapen!

Always make sure the hose package is straight when replacing the wire guide.

The illustration serves as an example only.




Figure 5-5

1.




Figure 5-6

2.






Figure 5-7

3.




4.


Adjust the brass liner > see 5.5 chapter.



5.



6.



7.




Figure 5-12

8.




Figure 5-13

Item	Symbol	Description
1		Extraction nozzle
2		Gas nozzle
3		Contact tip
4		Contact tip holder
5		Torch neck 45°
6		Crown nut
7		O-ring
8		Collet
9		Combined liner
10		Euro central connection
11		Connecting sleeve
12		New combined liner
13		Liner sharpener > see 9 chapter
14		Guiding tube for welding torch Euro torch connector

5.6.4 Guide spiral

 **Observe permissible torque > see 8 chapter!**

Insert the grinded end towards the contact tip holder to ensure tight fit with the contact tip.
Always make sure the hose package is straight when replacing the wire guide.
The illustration serves as an example only.




Figure 5-14

1.




Figure 5-15

2.




Figure 5-16

3.




Figure 5-17

4.




Figure 5-18

5.




Figure 5-19

6.




Figure 5-20

7.




Figure 5-21

Item	Symbol	Description
1		Extraction nozzle
2		Gas nozzle
3		Contact tip
4		Contact tip holder
5		Torch neck 45°
6		Crown nut, welding torch central connection (euro)
7		Centring sleeve
8		old spiral guide
9		Euro central connection
10		new spiral guide
11		Capillary tube

5.7 Setting the welding smoke flow rate

5.7.1 Test preparation

- Before checking the flow rate, it is necessary to measure the amount of shielding gas.
- The quantity of shielding gas is measured at the gas nozzle of the welding torch and is set either directly on the pressure regulator or, if available, on the gas control unit of the wire feeder or power source.
- Connect the welding torch to the welding machine or wire feeder.
- Connect the welding fume extractor hose to the welding torch using an adapter > see 9 chapter.
- Connect the welding fume extractor hose to the extraction system

The welding smoke flow rate can be influenced by using the bypass slider.

The illustration serves as an example only.




Figure 5-22

Item	Symbol	Description
1		Bypass slider, extraction capacity
2		Welding fume extractor
3		Nozzle holder with diaphragm grommet
4		Extraction nozzle
5		Scale Welding smoke flow rate (values > see 8 chapter)
6		Endcap
7		AirFlow Meter - Airflow meter assembly > see 9 chapter
8		O-ring for floats
9		Float
10		Measuring tube

5.7.2 Checking the flow rate of the welding fumes

- Setting values of the welding smoke flow rate > see 8 chapter.
- Calculate the welding smoke flow rate as a function of the altitude > see 12.1 chapter.
- Insert the welding fume extractor torch with the welding fume extraction nozzle installed vertically from above as far as it will go into the nozzle holder of the airflow meter.
- The airflow meter must also be held with one hand at the top (green ticks).
- The intake opening at the bottom must not be covered by fingers or a hand (red cross).
- The minimum distance between the airflow meter and an object should be at least 50 cm / 19.7 inches.
- The openings of the welding fume extraction nozzle must not be clogged and must be free of dirt.
- The openings of the extraction nozzle must be located completely inside the airflow meter and must not be covered by the diaphragm grommet of the nozzle holder.
- Note the installation direction of the floater. The O-ring of the floater must point downwards.
- The welding fume extraction nozzle of the welding fume extractor torch must sit precisely in the airflow meter.
- Close the bypass slider on the welding fume extractor torch.
- Switch on the filter and extraction system.
- The welding smoke flow rate is indicated at the centre of the O-ring of the floater, on the scale of the airflow meter's measuring tube.
- Readjust the welding fume flow rate on the controller of the extraction system until the specified value Q_{vm} and the displayed value match.

5.8 Function specification

5.8.1 General

A usable MIG/MAG welding torch consists of: Tube package, handle and torch neck with the relevant fittings and consumable parts.

All elements together form a functional unit which, supplied with the relevant operating materials, generates an arc for welding. For welding, a wire electrode is fed through the tube package and the welding torch. The arc and molten pool are shielded using inert gas (MIG) or active gas (MAG).

The wire electrode is a melting solid or cored wire which is conveyed through the contact nozzle. The contact nozzle transfers the welding current onto the wire electrode. The arc is formed between the wire electrode and workpiece. The welding torches are gas or fluid cooled depending on the version. The tube package is equipped accordingly.

The torch button on the MIG welding torch is normally used for starting and stopping the welding process. The operating elements on the UP/DOWN torch and POWERCONTROL torch provide additional functions over and above those of a standard torch.

Removing the extraction nozzle during welding leads to a reduction in welding smoke capture. As a result, the welding torch no longer conforms to the standard and the performance specifications in the technical data.

6 Maintenance, care and disposal

6.1 General

DANGER



Risk of injury due to electrical voltage after switching off!

Working on an open machine can lead to fatal injuries!

Capacitors are loaded with electrical voltage during operation. Voltage remains present for up to four minutes after the mains plug is removed.

1. Switch off machine.
2. Remove the mains plug.
3. Wait for at least 4 minutes until the capacitors have discharged!

WARNING



Improper maintenance, testing and repairs!

Maintenance, testing and repair of the machine may only be carried out by skilled and qualified personnel (authorised service personnel). A competent person is someone who, based on training, knowledge and experience, can recognize the hazards and possible consequential damage that may occur when testing power sources and can take the necessary safety precautions.

- Follow the maintenance instructions > see 6.1.3 chapter.
- If any of the test requirements below are not met, the unit must not be put back into operation until it has been repaired and tested again.

Repair and maintenance work may only be performed by qualified authorised personnel; otherwise the right to claim under warranty is void. In all service matters, always consult the dealer who supplied the machine. Return deliveries of defective equipment subject to warranty may only be made through your dealer. When replacing parts, use only original spare parts. When ordering spare parts, please quote the machine type, serial number and item number of the machine, as well as the type designation and item number of the spare part.

The welding torch is one of the most stressed components of the welding system. Due to the high thermal load and contamination, regular maintenance and care not only extends the service life of the system but also saves costs in the long term through the use of fewer replacement parts and less downtime. Perfect welding results can only be achieved with a properly maintained welding torch.

For maintenance and care, use only the tools, aids and tightening torques specified in the operating instructions.

6.1.1 Identifying damage or worn components

Contact tip

- Oval, ground bore at the wire outlet
- Clinging weld spatter that can no longer be removed
- Penetration or burn-off at the contact tip
- Contact tip that sits eccentrically

Gas nozzle

- Clinging weld spatter, deformation, notches, penetration and damaged threads
- The O-ring of the gas nozzle holder is worn (for water-cooled welding torches)

Gas diffuser

- Clogged bores, cracks, burnt-off outer edges

Contact tip holder

- The key flat is defective or worn, thread damaged, clinging weld spatter

Torch head

- The thread is defective or worn

Euro torch connector

- The O-ring of the connecting nipple for shielding gas is defective or worn
- The spring pins of the torch trigger are bent, jammed or dirty
- The thread of the crown nut is dirty or damaged
- For water-cooled welding torches, check the coolant connections for damage

Grip

- Cracks, penetration

Hose package

- Cracks, penetration



To prevent damage to and malfunction of the welding torch and hose package:

- **Never strike hard objects (hammering)!**
- **Do not use the welding torch for levering or straightening!**
- **Do not bend the torch neck! Bending flexible torch necks is possible considering the maximum bending cycles.**
- **Do not twist the hose package to no end in one direction. It is necessary to untwist it regularly.**
- **During breaks or after work, place the welding torch in the torch holder provided on the welding machine or at the workplace!**
- **Never throw the welding torch!**
- **Do not pull welding machines / wire feeders with the welding torch!**




Figure 6-1

6.1.2 Maintenance and care before each use




Figure 6-2



Welding spatter protection spray must not be used on the gas nozzle of the welding fume extractor torch or other components. The aerosols clog the filters of the extraction system.

- Loosen the gas nozzle, check the replacement parts for damage, replace if necessary and ensure a tight fit.
- Clean and remove soiling and welding spatter from the welding torch and, particularly, the wear parts; replace any worn or defective parts, if necessary.
- Check the O-rings on the torch neck and Euro torch connector for damage and presence. Replace defective O-ring.
- With water-cooled welding torches, check the coolant connections for tightness and flow. Check the coolant fill level at the cooling unit.
- Check the grip and hose package for cracks and damage.

6.1.3 Regular maintenance

The regular maintenance of a welding torch depends heavily on the duration of use and the stress and must be specified by the operator / owner. As a rule of thumb, every time the wire spool or wire basket is replaced or, if necessary, at a change of shift.




Figure 6-3

- Disconnect the welding torch from the machine, remove the replacement parts and blow out the wire duct and gas connection of the torch alternately with compressed air (max. 4 bar) free of oil and condensed water.
- Mount the replacement parts, connect the welding torch to the machine and purge twice with shielding gas (gas test).
- Check the liner or steel liner for damage and replace if necessary.
- Check the coolant container for sludge deposits and check the coolant for cloudiness. Clean the coolant container if contaminated, and change the coolant.
- If the coolant is dirty, rinse through the welding torch alternately several times with fresh coolant using the coolant return and supply.
- Check the screw and plug connectors of connections for proper seating and tighten if necessary.

6.2 Disposing of equipment



Proper disposal!

The machine contains valuable raw materials, which should be recycled, and electronic components, which must be disposed of.

- Do not dispose of in household waste!
- Observe the local regulations regarding disposal!

In addition to the national or international regulations mentioned below, it is mandatory to follow the respective national laws and regulations on disposal.

- According to European provisions (Directive 2012/19/EU on Waste of Electrical and Electronic Equipment), used electric and electronic equipment may no longer be placed in unsorted municipal waste. It must be collected separately. The symbol depicting a waste container on wheels indicates that the equipment must be collected separately.

This machine has to be disposed of, or recycled, in accordance with the waste separation systems in use.

According to German law (law governing the distribution, taking back and environmentally correct disposal of electrical and electronic equipment (ElektroG)), used machines are to be placed in a collection system separate from unsorted municipal waste. The public waste management utilities (communities) have created collection points at which used equipment from private households can be disposed of free of charge.

The deletion of personal data is the responsibility of the end user.

Lamps, batteries or accumulators must be removed and disposed of separately before disposing of the device. The type of battery or accumulator and its composition is marked on the top (type CR2032 or SR44). The following EWM products may contain batteries or accumulators:

- Welding helmets
Batteries or accumulators are easy to remove from the LED cassette.
- Device controls
Batteries or accumulators are located on the back of these in corresponding sockets on the circuit board and are easy to remove. The controls can be removed using standard tools.

Information on returning used equipment or collections can be obtained from the respective municipal administration office. Devices can also be returned to EWM sales partners across Europe.

Further information on the topic of the disposal of electrical and electronic equipment can be found on our website at: <https://www.ewm-group.com/de/nachhaltigkeit.html>.

7 Rectifying faults

All products are subject to rigorous production checks and final checks. If, despite this, something fails to work at any time, please check the product using the following flowchart. If none of the fault rectification procedures described leads to the correct functioning of the product, please inform your authorised dealer.

7.1 Checklist for rectifying faults

The correct machine equipment for the material and process gas in use is a fundamental requirement for perfect operation!

Legend	Symbol	Description
	↗	Fault/Cause
	✘	Remedy

Welding torch overheated

- ↗ Loose welding current connections
 - ✘ Tighten power connections on the torch and/or on the workpiece
 - ✘ Tighten contact tip correctly
- ↗ Overload
 - ✘ Check and correct welding current setting
 - ✘ Use a more powerful welding torch
- ↗ High welding fume load
 - ✘ Reduce the welding fume extraction rate.
 - ✘ Clean the welding torch.
 - ✘ If necessary, close the bypass slider on the welding torch.
 - ✘ Properly attach the extraction nozzle and extraction hose and check for leak-tightness.
 - ✘ The extraction nozzle openings must be free of deposits.
 - ✘ Ensure that the extraction system is switched on.
 - ✘ Check the extraction system filter and replace it if saturated.

Wire feed problems

- ✓ Unsuitable or worn welding torch equipment
 - ✘ Adjust contact tip to wire diameter and -material and replace if necessary
 - ✘ Adjust wire guide to material in use, blow through and replace if necessary
- ✓ Kinked hose packages
 - ✘ Extend and lay out the torch hose package
- ✓ Incompatible parameter settings
 - ✘ Check settings and correct if necessary
- ✓ Contact tip blocked
 - ✘ Clean and, if necessary, replace.
- ✓ Setting the spool brake
 - ✘ Check settings and correct if necessary
- ✓ Setting pressure units
 - ✘ Check settings and correct if necessary
- ✓ Worn wire rolls
 - ✘ Check and replace if necessary
- ✓ Wire feed motor without supply voltage (automatic cutout triggered by overloading)
 - ✘ Reset triggered fuse (rear of the power source) by pressing the key button
- ✓ Wire guide core or spiral is dirty or worn
 - ✘ Clean core or spiral; replace kinked or worn cores
- ✓ Arc between gas nozzle and workpiece (metal vapour on the gas nozzle)
 - ✘ Replace gas nozzle
 - ✘ Clean the gas nozzle, contact tip, contact tip holder and gas diffuser and replace if they are worn.

Unstable arc

- ✓ Unsuitable or worn welding torch equipment
 - ✘ Adjust contact tip to wire diameter and -material and replace if necessary
 - ✘ Adjust wire guide to material in use, blow through and replace if necessary
- ✓ Incompatible parameter settings
 - ✘ Check settings and correct if necessary


Pore formation

- ✓ Inadequate or missing gas shielding
 - ✘ Check shielding gas setting and replace shielding gas cylinder if necessary
 - ✘ Shield welding site with protective screens (draughts affect the welding result)
 - ✘ Use gas lens for aluminium applications and high-alloy steels
 - ✘ Check the welding smoke flow rate using an airflow meter and if necessary correct
 - ✘ Depending on the application, reduce the welding fume flow rate using the bypass slider.
- ✓ Unsuitable or worn welding torch equipment
 - ✘ Check size of gas nozzle and replace if necessary
 - ✘ Check the O-ring on the Euro torch connector and if necessary replace.
- ✓ Condensation in the gas tube
 - ✘ Purge hose package with gas or replace

8 Technical data

Performance specifications and guarantee only in connection with original spare and replacement parts!

8.1 MT 221-, MT 301G F2


	221 G F2	301 G F2
Welding torch polarity	Usually positive	
Guide type	Manually operated	
Voltage type	Direct voltage DC	
Shielding gas	Shielding gas according to ISO 14175	
Duty cycle DC at 40° C ^[1]	35 % / 60 %	
Maximum welding current CO ²	300 A / 250 A	380 A / 330 A
Maximum welding current M21	250 A / 220 A	330 A / 300 A
Maximum welding current pulse M21	170 A / 150 A	220 A / 210 A
Switching voltage Push-button	15 V	
Switching current Push-button	10 mA	
Flow rate Connector Q _{vc} ^[2]	59 m ³ /h	77 m ³ /h
Flow rate Nozzle Q _{vn} ^[2]	47 m ³ /h	59 m ³ /h
Low pressure Connector Δ _{pc} ^{[2] [3]}	13570 Pa	6165 Pa
Wire types	Standard round wires	
Wire diameter	0,8 - 1,2 mm	0,8 - 1,6 mm
Ambient temperature	-10 °C to + 40 °C	
Voltage measurement	113 V (Peak value)	
Protection classification for the machine connections (EN 60529)	IP3X	
Gas flow	10 to 20 l/min	
Hose package length	3-, 4-, 5 m	
Tightening torque Contact tip holder	max. 10 Nm	max. 15 Nm
Tightening torque Contact tip	max. 5 Nm	max. 10 Nm
Connection	Euro torch connector	
Operating weight 	1,09 kg	1,16 kg
Standards used	See declaration of conformity (appliance documents)	
Test mark	CE / EAC / UK	

^[1] Load cycle: 10 min. (60 % DC \triangleq 6 min. welding, 4 min. pause)

^[2] > see 8.3.1 chapter.

^[3] Reference altitude sea level (SL) > see 12.1 chapter

8.2 MT 221-, MT 301G F3


	221 G F3	301 G F3
Welding torch polarity	Usually positive	
Guide type	Manually operated	
Voltage type	Direct voltage DC	
Shielding gas	Shielding gas according to ISO 14175	
Duty cycle DC at 40° C ^[1]	35 % / 60 %	
Maximum welding current CO ²	300 A / 250 A	380 A / 330 A
Maximum welding current M21	250 A / 220 A	330 A / 300 A
Maximum welding current pulse M21	170 A / 150 A	220 A / 210 A
Switching voltage Push-button	15 V	
Switching current Push-button	10 mA	
Flow rate Connector Q _{vc} ^[2]	52 m ³ /h	133 m ³ /h
Flow rate Nozzle Q _{vn} ^[2]	42,8 m ³ /h	79,8 m ³ /h
Low pressure Connector Δ _{pc} ^{[2] [3]}	4000 Pa	11000 Pa
Wire types	Standard round wires	
Wire diameter	0,8 - 1,2 mm	0,8 - 1,6 mm
Ambient temperature	-10 °C to + 40 °C	
Voltage measurement	113 V (Peak value)	
Protection classification for the machine connections (EN 60529)	IP3X	
Gas flow	10 to 20 l/min	
Hose package length	3-, 4-, 5 m	
Tightening torque Contact tip holder	max. 10 Nm	max. 15 Nm
Tightening torque Contact tip	max. 5 Nm	max. 10 Nm
Connection	Euro torch connector	
Operating weight	1,02 kg	1,12 kg
		
Standards used	See declaration of conformity (appliance documents)	
Test mark	CE / EAC / UK	

^[1] Load cycle: 10 min. (60 % DC \triangleq 6 min. welding, 4 min. pause)

^[2] > see 8.3.1 chapter.

^[3] Reference altitude sea level (SL) > see 12.1 chapter

8.3 MT- / PM 221G, - 301G,- 401G with conversion kit ON SRA-Kit PM / MT

	221 G	301 G	401 G
Welding torch polarity	Usually positive		
Guide type	Manually operated		
Voltage type	Direct voltage DC		
Shielding gas	Shielding gas according to ISO 14175		
Duty cycle DC at 40° C ^[1]	35 % / 60 %		
Maximum welding current CO²	300 A / 250 A	380 A / 330 A	450 A / -
Maximum welding current M21	250 A / 220 A	330 A / 300 A	400 A / -
Maximum welding current pulse M21	170 A / 150 A	220 A / 210 A	260 A / -
Switching voltage Push-button	15 V		
Switching current Push-button	10 mA		
Flow rate Connector Q_{vc} ^[2]	71 m ³ /h	73 m ³ /h	78 m ³ /h
Flow rate Nozzle Q_{vn} ^[2]	58 m ³ /h	60 m ³ /h	64 m ³ /h
Low pressure Connector Δ_{pc} ^{[2] [3]}	7957 Pa	8365 Pa	10813 Pa
Wire types	Standard round wires		
Wire diameter	0,8 - 1,2 mm	0,8 - 1,6 mm	0,8 - 2,0 mm
Ambient temperature	-10 °C to + 40 °C		
Voltage measurement	113 V (Peak value)		
Protection classification for the machine connections (EN 60529)	IP3X		
Gas flow	10 to 20 l/min		
Hose package length	3-, 4-, 5 m		
Tightening torque Contact tip holder	max. 10 Nm	max. 15 Nm	
Tightening torque Contact tip	max. 5 Nm	max. 10 Nm	
Connection	Euro torch connector		
Operating weight	1,09 kg 2.4 lb	1,16 kg 2.56 lb	1,3 kg 2.86 lb
			
Standards used	See declaration of conformity (appliance documents)		
Test mark	CE / ENEC / UK		

^[1] Load cycle: 10 min. (60 % DC \triangleq 6 min. welding, 4 min. pause)

^[2] > see 8.3.1 chapter.

^[3] Reference altitude sea level (SL) > see 12.1 chapter

8.3.1 Explanation of terms




Figure 8-1

Item	Symbol	Description
1	Q_{vn}	Flow-rate nozzle
2	Δ_{pc}	Vacuum connector
3	Q_{vc}	Flow rate connector

9 Accessories

Performance-dependent accessories like torches, workpiece leads, electrode holders or intermediate hose packages are available from your authorised dealer.

9.1 List of tools

Type	Designation	Item no.
Cutter	Hose cutter	094-016585-00000
DSP	Sharpener for liner	094-010427-00000
SW5-SW12MM	Torch key	094-016038-00001
O-Ring Picker	O-ring picker	098-005149-00000
CBB Ø 15 mm	Cylinder brushes, brass wire 15mm	098-005208-00000
CBB Ø 20 mm	Cylinder brushes, brass wire 20mm	098-005209-00000
3 x 5/6	Spark plug brush	098-004718-00000
ADAP CZA	Adapter for welding torches from Euro torch connector to CLOOS connector (gas/water on the outside)	094-019852-00000
ADAP EZA/DZA	Adapter for welding torches from Euro torch connector to DINSE connector on the machine	394-000134-00000

9.2 Dimensions

Type	Designation	Item no.
AirFlow Meter	Airflow meter assembly	092-004851-00000

9.2.1 Spare parts for airflow meters

Type	Designation	Item no.
MBDT D68X10,1	Diaphragm grommet	059-003992-00000

9.3 Adapter for welding fume extractor torch F3

Type	Designation	Item no.
ADAP PVCE NW 44	Adapter for extraction hose with nominal diameter of 44 mm	096-001280-00000
ADAP PVCE NW 51	Adapter for extraction hose with nominal diameter of 51 mm	398-004591-00000

9.4 Extraction hose

Type	Designation	Item no.
NW 44 mm 1 m	Extraction hose, nominal diameter 44 mm	092-004032-00010
NW 44 mm 3 m	Extraction hose, nominal diameter 44 mm	092-004032-00030
NW 44 mm 5 m	Extraction hose, nominal diameter 44 mm	092-004032-00050
NW 44 mm 7,5 m	Extraction hose, nominal diameter 44 mm	092-004032-00075
NW 51 mm 1 m	Extraction hose, nominal diameter 51 mm	092-004033-00010
NW 51 mm 3 m	Extraction hose, nominal diameter 51 mm	092-004033-00030
NW 51 mm 5 m	Extraction hose, nominal diameter 51 mm	092-004033-00050
NW 51 mm 7,5 m	Extraction hose, nominal diameter 51 mm	092-004033-00075

9.5 Replacement parts set

Type	Designation	Item no.
SRP MT221G/MT301W ST/CR M6	Replacement parts set, steel/chrome nickel	092-013427-40000
SRP MT221G/MT301W AL M6	Replacement parts set, aluminium	092-013427-40001
SRP MT221G/MT301W ST/CR M7	Replacement parts set, steel/chrome nickel	092-013427-30000
SRP MT221G/MT301W AL M7	Replacement parts set, aluminium	092-013427-30001
SRP MT301G/MT451W ST/CR M8	Replacement parts set, steel/chrome nickel	092-013428-40000
SRP MT301G/MT451W AL M8	Replacement parts set, aluminium	092-013428-40001
SRP MT301G/MT451W ST/CR M9	Replacement parts set, steel/chrome nickel	092-013428-30000
SRP MT301G/MT451W AL M9	Replacement parts set, aluminium	092-013428-30001

9.6 Option

Type	Designation	Item no.
ON SRA-Kit PM / MT 221G / 301W	Welding fume extractor kit for PM 221 G / MT221G and PM 301 W / MT301W	092-007945-00000
ON SRA-Kit PM / MT 301G	Welding fume extractor kit for PM 301 G / MT301G	092-007951-00000
ON SRA-Kit PM / MT 401G	Welding fume extractor kit for PM 401 G / MT401G	092-007952-00000
ON AA NW44	Adapter for welding fume extractor torch "F2" for connection to extraction hose Ø 44 mm	094-026782-00000
ON AA NW51	Adapter for welding fume extractor torch "F2" for connection to extraction hose Ø 51 mm	094-026788-00000
ON TS F2/F3 D.01	Holder for fume extraction torch	092-004323-00000
ON LS KV Ø 53 mm 5 m	Leather tube with hook and loop fastener	094-027749-00000

10 Replaceable parts



The manufacturer's warranty becomes void if non-genuine parts are used!

- *Only use system components and options (power sources, welding torches, electrode holders, remote controls, spare parts and replacement parts, etc.) from our range of products!*
- *Only insert and lock accessory components into the relevant connection socket when the machine is switched off.*

10.1 MT221 G F2, -F3




Figure 10-1

Item	Order number	Type	Designation
1.1	094-013061-00001	GN TR 20 66mm Ø 13mm	Gas nozzle
1.1	094-013062-00001	GN TR 20 66mm Ø 11mm	Gas nozzle
1.1	094-013063-00001	GN TR 20 66mm Ø 16mm	Gas nozzle
1.2 *	094-020136-00000	GN TR 20x4 68mm Ø 10,5mm	Gas nozzle, cylinder neck
1.2 *	094-023817-00000	GN TR 20x4 61,3mm Ø 10,5mm	Gas nozzle, cylinder neck
1.3	094-013644-00000	GN FCW TR 20 58mm	Gas nozzle, inner shield
1.6	094-020944-00000	GN TR 20, 75 mm, Ø 18 mm	Spot welding nozzle
2	094-013071-00000	CT CuCrZr M6 x 28mm Ø 0.8mm	Contact tip
2	094-013122-00000	CT CuCrZr M6 x 28mm Ø 0.9mm	Contact tip
2	094-013072-00000	CT CuCrZr M6 x 28mm Ø 1.0mm	Contact tip
2	094-014317-00000	CT CuCrZr M6 x 28mm Ø 1.2mm	Contact tip
2	094-013535-00001	CT CuCrZr M7 x 30mm Ø 0.8mm	Contact tip
2	094-013536-00001	CT CuCrZr M7 x 30mm Ø 0.9mm	Contact tip
2	094-013537-00001	CT CuCrZr M7 x 30mm Ø 1.0mm	Contact tip
2	094-013538-00001	CT CuCrZr M7 x 30mm Ø 1.2mm	Contact tip
2	094-013550-00001	CTAL E-Cu M7 x 30mm Ø 0.8mm	Contact tip, aluminium welding
2	094-013551-00001	CTAL E-Cu M7 x 30mm Ø 0.9mm	Contact tip, aluminium welding
2	094-013552-00001	CTAL E-Cu M7 x 30mm Ø 1.0mm	Contact tip, aluminium welding
2	094-013553-00001	CTAL E-Cu M7 x 30mm Ø 1.2mm	Contact tip, aluminium welding
2	094-016101-00000	CT E-Cu M6 x 28mm Ø 0.8mm	Contact tip

Item	Order number	Type	Designation
2	094-016102-00000	CT E-Cu M6 x 28mm Ø 0.9mm	Contact tip
2	094-016103-00000	CT E-Cu M6 x 28mm Ø 1.0mm	Contact tip
2	094-016104-00000	CT E-Cu M6 x 28mm Ø 1.2mm	Contact tip
2	094-016105-00000	CTAL E-Cu M6 X 28 mm Ø 0.8 mm	Contact tip, aluminium welding
2	094-016106-00000	CTAL E-Cu M6 X 28 mm Ø 0.9 mm	Contact tip, aluminium welding
2	094-016107-00000	CTAL E-Cu M6 X 28 mm Ø 1.0 mm	Contact tip, aluminium welding
2	094-016108-00000	CTAL E-Cu M6 X 28 mm Ø 1.2 mm	Contact tip, aluminium welding
2.2	094-005403-00000	CT CuCrZr M6 x 25mm Ø 0.6mm	Contact tip
2.2	094-020689-00000	CT CuCrZr M6 x 25mm Ø 0.8mm	Contact tip
2.2	094-020690-00000	CT CuCrZr M6 x 25mm Ø 1.0mm	Contact tip
2.2	094-020691-00000	CT E-Cu M6 x 25mm Ø 0.6mm	Contact tip
2.2	094-020692-00000	CT E-Cu M6 x 25mm Ø 0.8mm	Contact tip
2.2	094-020693-00000	CT E-Cu M6 x 25mm Ø 0.9mm	Contact tip
2.2	094-020694-00000	CT E-Cu M6 x 25mm Ø 1.0mm	Contact tip
2.2	094-020695-00000	CTAL E-Cu M6 x 25mm Ø 0.6mm	Contact tip, aluminium welding
2.2	094-020696-00000	CTAL E-Cu M6 x 25mm Ø 0.8mm	Contact tip, aluminium welding
2.2	094-020697-00000	CTAL E-Cu M6 x 25mm Ø 0.9mm	Contact tip, aluminium welding
2.2	094-020698-00000	CTAL E-Cu M6 x 25mm Ø 1.0mm	Contact tip, aluminium welding
2.3	094-025535-00000	CT ZWK CuCrZr M7 x 30 mm Ø 1,0 mm	Contact tip, forced contact
2.3	094-025536-00000	CT ZWK CuCrZr M7 x 30 mm Ø 1,2 mm	Contact tip, forced contact
3	094-013069-00002	CTH CuCrZr M6 x 30.5mm	Contact tip holder
3	094-013070-00002	CTH CuCrZr M6 x 33.5mm	Contact tip holder
3	094-013541-00002	CTH CuCrZr M7 x 31.5mm	Contact tip holder
3	094-013542-00002	CTH CuCrZr M7 x 34.5mm	Contact tip holder
3.1	094-020562-00000	CTH CuCrZr M6 x 30.5mm	Contact tip holder
4	094-013094-00004	GD Ø9,5 mm, L=10,5 mm	Gas diffuser
5	094-026560-00003	SRAD DN 23 mm, Ø 38 mm, L 82 mm	Welding fume extraction nozzle, conical
5.1	094-026559-00001	SRAD DN 23 mm, Ø 38 mm, L 64 mm	Welding fume extraction nozzle, cylindrical
5.2	094-026511-00000	SRAD DN 23 mm, Ø 38 mm, L 33 mm	Welding fume extraction nozzle, cylindrical
	094-013967-00000	4,0MMX1,0MM	O-ring for Euro torch connector

* Only possible in combination with cylindrical welding fume extraction nozzles, i.e. 5.1 and 5.2.


10.2 MT301G F2, -F3


Figure 10-2

Item	Order number	Type	Designation
1	094-013105-00001	GN TR 22 71mm Ø 13mm	Gas nozzle
1	094-013106-00001	GN TR 22 71mm Ø 15mm	Gas nozzle
1	094-013107-00001	GN TR 22 71mm Ø 18mm	Gas nozzle
1	094-019821-00001	GN TR 22 65mm Ø 15mm	Gas nozzle, short
1	094-019822-00001	GN TR 22 65mm Ø 18mm	Gas nozzle, short
1.1	094-019853-00001	GN NG TR22x4 71mm Ø 13mm	Highly conical gas nozzle, narrow gap welding
1.3	094-019554-00000	GN FCW TR 22x4 59.5mm	Gas nozzle, inner shield
1.4	094-019626-00000	GN NG M12 73mm	Gas nozzle, narrow gap welding
1.4	094-022226-00000	GN NG M12 76mm	Gas nozzle, narrow gap welding
1.5	094-019623-00000	GNC TR22x4	Gas nozzle body
1.6	094-020945-00000	GN TR 22 80mm Ø 20mm	Spot welding nozzle
2	094-014024-00000	CT M8 CuCrZr 30mm, Ø 0.8mm	Contact tip
2	094-013129-00000	CT M8 CuCrZr 30mm, Ø 0.9mm	Contact tip
2	094-014222-00000	CT M8 CuCrZr 30mm, Ø 1.0mm	Contact tip
2	094-013113-00000	CT M8 CuCrZr 30mm, Ø 1.2mm	Contact tip
2	094-014191-00000	CT M8 CuCrZr 30mm, Ø 1.4mm	Contact tip
2	094-014192-00000	CT M8 CuCrZr 30mm, Ø 1.6mm	Contact tip
2	094-013528-00001	CT CuCrZr M9 x 35mm Ø 0.8mm	Contact tip
2	094-013529-00001	CT CuCrZr M9 x 35mm Ø 0.9mm	Contact tip
2	094-013530-00001	CT CuCrZr M9 x 35mm Ø 1.0mm	Contact tip
2	094-013531-00001	CT CuCrZr M9 x 35mm Ø 1.2mm	Contact tip
2	094-013532-00001	CT CuCrZr M9 x 35mm Ø 1.4mm	Contact tip

Item	Order number	Type	Designation
2	094-013533-00001	CT CuCrZr M9 x 35mm Ø 1.6mm	Contact tip
2	094-013543-00001	CTAL E-Cu M9 x 35mm Ø 0.8mm	Contact tip, aluminium welding
2	094-013544-00001	CTAL E-Cu M9 x 35mm Ø 0.9mm	Contact tip, aluminium welding
2	094-013545-00001	CTAL E-Cu M9 x 35mm Ø 1.0mm	Contact tip, aluminium welding
2	094-013546-00001	CTAL E-Cu M9 x 35mm Ø 1.2mm	Contact tip, aluminium welding
2	094-013547-00001	CTAL E-Cu M9 x 35mm Ø 1.4mm	Contact tip, aluminium welding
2	094-013548-00001	CTAL E-Cu M9 x 35mm Ø 1.6mm	Contact tip, aluminium welding
2	094-016109-00000	CT E-Cu M8 x 30mm Ø 0.8mm	Contact tip
2	094-016110-00000	CT E-Cu M8 x 30mm Ø 0.9mm	Contact tip
2	094-016111-00000	CT E-Cu M8 x 30mm Ø 1.0mm	Contact tip
2	094-007238-00000	CT E-Cu M8 x 30mm Ø 1.2mm	Contact tip
2	094-016112-00000	CT E-Cu M8 x 30mm Ø 1.4mm	Contact tip
2	094-016113-00000	CT E-Cu M8 x 30mm Ø 1.6mm	Contact tip
2	094-016115-00000	CT E-Cu M8 x 30mm Ø 0.8mm	Contact tip, aluminium welding
2	094-016116-00000	CT E-Cu M8 x 30mm Ø 0.9mm	Contact tip, aluminium welding
2	094-016117-00000	CT E-Cu M8 x 30mm Ø 1.0mm	Contact tip, aluminium welding
2	094-016118-00000	CT E-Cu M8 x 30mm Ø 1.2mm	Contact tip, aluminium welding
2	094-016119-00000	CT E-Cu M8 x 30mm Ø 0.8mm	Contact tip, aluminium welding
2	094-016120-00000	CT E-Cu M8 x 30mm Ø 0.8mm	Contact tip, aluminium welding
2.1	094-019616-00000	CT CuCrZr M9 x 100mm Ø 1.0mm	Contact tip, narrow gap welding
2.1	094-019617-00000	CT CuCrZr M9 x 100mm Ø 1.2mm	Contact tip, narrow gap welding
2.1	094-019618-00000	CT CuCrZr M9 x 100mm Ø 1.6mm	Contact tip, narrow gap welding
2.1	094-020019-00000	CT CuCrZr M9 x 100mm Ø 1.4mm	Contact tip, narrow gap welding
2.3	094-017007-00001	CT ZWK CuCrZr M9x35 mm Ø 1,0 mm	Contact tip, forced contact
2.3	094-016159-00001	CT ZWK CuCrZr M9x35 mm Ø 1,2 mm	Contact tip, forced contact
2.3	094-025533-00001	CT ZWK CuCrZr M9x35 mm Ø 1,6 mm	Contact tip, forced contact
3	094-013109-00003	CTH CuCrZr M8 x 34.1mm	Contact tip holder
3	094-013110-00002	CTH CuCrZr M8 x 37.1mm	Contact tip holder
3	094-013539-00002	CTH CuCrZr M9 x 34.5mm	Contact tip holder
3	094-013540-00002	CTH CuCrZr M9 x 37.5mm	Contact tip holder
4	094-013096-00004	GD Ø11,7 mm, L=11,9 mm	Gas diffuser
5	094-019625-00000	IT ES M22X1,5 M12X1	Insulation part
6	094-019627-00000	ZH GDE 15mm Ø 5mm x 10mm	Centring sleeve
8	094-026557-00003	SRAD DN 25 mm, Ø 41 mm, L 41 mm	Welding fume extraction nozzle, conical
8.1	094-026556-00001	SRAD DN 25 mm, Ø 41 mm, L 23 mm	Welding fume extraction nozzle, cylindrical
	094-013967-00000	4,0MMX1,0MM	O-ring for Euro torch connector

10.3 MT- / PM 221G (ON SRA-Kit PM / MT 221G / 301W)




Figure 10-3

Item	Order number	Type	Designation
1.1	094-013061-00001	GN TR 20 66mm Ø 13mm	Gas nozzle
1.1	094-013062-00001	GN TR 20 66mm Ø 11mm	Gas nozzle
1.1	094-013063-00001	GN TR 20 66mm Ø 16mm	Gas nozzle
1.2 *	094-020136-00000	GN TR 20x4 68mm Ø 10,5mm	Gas nozzle, cylinder neck
1.2 *	094-023817-00000	GN TR 20x4 61,3mm Ø 10,5mm	Gas nozzle, cylinder neck
1.3	094-013644-00000	GN FCW TR 20 58mm	Gas nozzle, inner shield
1.6	094-020944-00000	GN TR 20, 75 mm, Ø 18 mm	Spot welding nozzle
2	094-013071-00000	CT CuCrZr M6 x 28mm Ø 0.8mm	Contact tip
2	094-013122-00000	CT CuCrZr M6 x 28mm Ø 0.9mm	Contact tip
2	094-013072-00000	CT CuCrZr M6 x 28mm Ø 1.0mm	Contact tip
2	094-014317-00000	CT CuCrZr M6 x 28mm Ø 1.2mm	Contact tip
2	094-013535-00001	CT CuCrZr M7 x 30mm Ø 0.8mm	Contact tip
2	094-013536-00001	CT CuCrZr M7 x 30mm Ø 0.9mm	Contact tip
2	094-013537-00001	CT CuCrZr M7 x 30mm Ø 1.0mm	Contact tip
2	094-013538-00001	CT CuCrZr M7 x 30mm Ø 1.2mm	Contact tip
2	094-013550-00001	CTAL E-Cu M7 x 30mm Ø 0.8mm	Contact tip, aluminium welding
2	094-013551-00001	CTAL E-Cu M7 x 30mm Ø 0.9mm	Contact tip, aluminium welding
2	094-013552-00001	CTAL E-Cu M7 x 30mm Ø 1.0mm	Contact tip, aluminium welding
2	094-013553-00001	CTAL E-Cu M7 x 30mm Ø1.2mm	Contact tip, aluminium welding
2	094-016101-00000	CT E-Cu M6 x 28mm Ø 0.8mm	Contact tip
2	094-016102-00000	CT E-Cu M6 x 28mm Ø 0.9mm	Contact tip
2	094-016103-00000	CT E-Cu M6 x 28mm Ø 1.0mm	Contact tip
2	094-016104-00000	CT E-Cu M6 x 28mm Ø 1.2mm	Contact tip
2	094-016105-00000	CTAL E-Cu M6 X 28 mm Ø 0.8 mm	Contact tip, aluminium welding
2	094-016106-00000	CTAL E-Cu M6 X 28 mm Ø 0.9 mm	Contact tip, aluminium welding
2	094-016107-00000	CTAL E-Cu M6 X 28 mm Ø 1.0 mm	Contact tip, aluminium welding
2	094-016108-00000	CTAL E-Cu M6 X 28 mm Ø 1.2 mm	Contact tip, aluminium welding

Replaceable parts

MT- / PM 221G (ON SRA-Kit PM / MT 221G / 301W)



Item	Order number	Type	Designation
2.2	094-005403-00000	CT CuCrZr M6 x 25mm Ø 0.6mm	Contact tip
2.2	094-020689-00000	CT CuCrZr M6 x 25mm Ø 0.8mm	Contact tip
2.2	094-020690-00000	CT CuCrZr M6 x 25mm Ø 1.0mm	Contact tip
2.2	094-020691-00000	CT E-Cu M6 x 25mm Ø 0.6mm	Contact tip
2.2	094-020692-00000	CT E-Cu M6 x 25mm Ø 0.8mm	Contact tip
2.2	094-020693-00000	CT E-Cu M6 x 25mm Ø 0.9mm	Contact tip
2.2	094-020694-00000	CT E-Cu M6 x 25mm Ø 1.0mm	Contact tip
2.2	094-020695-00000	CTAL E-Cu M6 x 25mm Ø 0.6mm	Contact tip, aluminium welding
2.2	094-020696-00000	CTAL E-Cu M6 x 25mm Ø 0.8mm	Contact tip, aluminium welding
2.2	094-020697-00000	CTAL E-Cu M6 x 25mm Ø 0.9mm	Contact tip, aluminium welding
2.2	094-020698-00000	CTAL E-Cu M6 x 25mm Ø 1.0mm	Contact tip, aluminium welding
2.3	094-025535-00000	CT ZWK CuCrZr M7 x 30 mm Ø 1,0 mm	Contact tip, forced contact
2.3	094-025536-00000	CT ZWK CuCrZr M7 x 30 mm Ø 1,2 mm	Contact tip, forced contact
3	094-013069-00002	CTH CuCrZr M6 x 30.5mm	Contact tip holder
3	094-013070-00002	CTH CuCrZr M6 x 33.5mm	Contact tip holder
3	094-013541-00002	CTH CuCrZr M7 x 31.5mm	Contact tip holder
3	094-013542-00002	CTH CuCrZr M7 x 34.5mm	Contact tip holder
3.1	094-020562-00000	CTH CuCrZr M6 x 30.5mm	Contact tip holder
4	094-013094-00004	GD Ø9,5 mm, L=10,5 mm	Gas diffuser
5	094-025863-00003	SRAD DN 23 mm, Ø 38 mm, L 60 mm	Welding fume extraction nozzle, conical
	094-013967-00000	4,0MMX1,0MM	O-ring for Euro torch connector

* Only possible in combination with cylindrical welding fume extraction nozzles, i.e. 5.1 and 5.2.

10.4 MT- / PM 301G (ON SRA-Kit PM / MT 301G)




Figure 10-4

Item	Order number	Type	Designation
1	094-013105-00001	GN TR 22 71mm Ø 13mm	Gas nozzle
1	094-013106-00001	GN TR 22 71mm Ø 15mm	Gas nozzle
1	094-013107-00001	GN TR 22 71mm Ø 18mm	Gas nozzle
1	094-019821-00001	GN TR 22 65mm Ø 15mm	Gas nozzle, short
1	094-019822-00001	GN TR 22 65mm Ø 18mm	Gas nozzle, short
1.1	094-019853-00001	GN NG TR22X4 71mm Ø 13mm	Highly conical gas nozzle, narrow gap welding
1.3	094-019554-00000	GN FCW TR 22x4 59.5mm	Gas nozzle, inner shield
1.4	094-019626-00000	GN NG M12 73mm	Gas nozzle, narrow gap welding
1.4	094-022226-00000	GN NG M12 76mm	Gas nozzle, narrow gap welding
1.5	094-019623-00000	GNC TR22x4	Gas nozzle body
1.6	094-020945-00000	GN TR 22 80mm Ø 20mm	Spot welding nozzle
2	094-014024-00000	CT M8 CuCrZr 30mm, Ø 0.8mm	Contact tip
2	094-013129-00000	CT M8 CuCrZr 30mm, Ø 0.9mm	Contact tip
2	094-014222-00000	CT M8 CuCrZr 30mm, Ø 1.0mm	Contact tip
2	094-013113-00000	CT M8 CuCrZr 30mm, Ø 1.2mm	Contact tip
2	094-014191-00000	CT M8 CuCrZr 30mm, Ø 1.4mm	Contact tip
2	094-014192-00000	CT M8 CuCrZr 30mm, Ø 1.6mm	Contact tip
2	094-013528-00001	CT CuCrZr M9 x 35mm Ø 0.8mm	Contact tip
2	094-013529-00001	CT CuCrZr M9 x 35mm Ø 0.9mm	Contact tip
2	094-013530-00001	CT CuCrZr M9 x 35mm Ø 1.0mm	Contact tip
2	094-013531-00001	CT CuCrZr M9 x 35mm Ø 1.2mm	Contact tip
2	094-013532-00001	CT CuCrZr M9 x 35mm Ø 1.4mm	Contact tip

Replaceable parts

MT- / PM 301G (ON SRA-Kit PM / MT 301G)



Item	Order number	Type	Designation
2	094-013533-00001	CT CuCrZr M9 x 35mm Ø 1.6mm	Contact tip
2	094-013543-00001	CTAL E-Cu M9 x 35mm Ø 0.8mm	Contact tip, aluminium welding
2	094-013544-00001	CTAL E-Cu M9 x 35mm Ø 0.9mm	Contact tip, aluminium welding
2	094-013545-00001	CTAL E-Cu M9 x 35mm Ø 1.0mm	Contact tip, aluminium welding
2	094-013546-00001	CTAL E-Cu M9 x 35mm Ø 1.2mm	Contact tip, aluminium welding
2	094-013547-00001	CTAL E-Cu M9 x 35mm Ø 1.4mm	Contact tip, aluminium welding
2	094-013548-00001	CTAL E-Cu M9 x 35mm Ø 1.6mm	Contact tip, aluminium welding
2	094-016109-00000	CT E-Cu M8 x 30mm Ø 0.8mm	Contact tip
2	094-016110-00000	CT E-Cu M8 x 30mm Ø 0.9mm	Contact tip
2	094-016111-00000	CT E-Cu M8 x 30mm Ø 1.0mm	Contact tip
2	094-007238-00000	CT E-Cu M8 x 30mm Ø 1.2mm	Contact tip
2	094-016112-00000	CT E-Cu M8 x 30mm Ø 1.4mm	Contact tip
2	094-016113-00000	CT E-Cu M8 x 30mm Ø 1.6mm	Contact tip
2	094-016115-00000	CT E-Cu M8 x 30mm Ø 0.8mm	Contact tip, aluminium welding
2	094-016116-00000	CT E-Cu M8 x 30mm Ø 0.9mm	Contact tip, aluminium welding
2	094-016117-00000	CT E-Cu M8 x 30mm Ø 1.0mm	Contact tip, aluminium welding
2	094-016118-00000	CT E-Cu M8 x 30mm Ø 1.2mm	Contact tip, aluminium welding
2	094-016119-00000	CT E-Cu M8 x 30mm Ø 0.8mm	Contact tip, aluminium welding
2	094-016120-00000	CT E-Cu M8 x 30mm Ø 0.8mm	Contact tip, aluminium welding
2.1	094-019616-00000	CT CuCrZr M9 x 100mm Ø 1.0mm	Contact tip, narrow gap welding
2.1	094-019617-00000	CT CuCrZr M9 x 100mm Ø 1.2mm	Contact tip, narrow gap welding
2.1	094-019618-00000	CT CuCrZr M9 x 100mm Ø 1.6mm	Contact tip, narrow gap welding
2.1	094-020019-00000	CT CuCrZr M9 x 100mm Ø 1.4mm	Contact tip, narrow gap welding
2.3	094-017007-00001	CT ZWK CuCrZr M9x35 mm Ø 1,0 mm	Contact tip, forced contact
2.3	094-016159-00001	CT ZWK CuCrZr M9x35 mm Ø 1,2 mm	Contact tip, forced contact
2.3	094-025533-00001	CT ZWK CuCrZr M9x35 mm Ø 1,6 mm	Contact tip, forced contact
3	094-013109-00003	CTH CuCrZr M8 x 34.1mm	Contact tip holder
3	094-013110-00002	CTH CuCrZr M8 x 37.1mm	Contact tip holder
3	094-013539-00002	CTH CuCrZr M9 x 34.5mm	Contact tip holder
3	094-013540-00002	CTH CuCrZr M9 x 37.5mm	Contact tip holder
4	094-013096-00004	GD Ø11,7 mm, L=11,9 mm	Gas diffuser
5	094-019625-00000	IT ES M22X1,5 M12X1	Insulation part
6	094-019627-00000	ZH GDE 15mm Ø 5mm x 10mm	Centring sleeve
8	094-026615-00002	SRAD DN 25 mm, Ø 41 mm, L 60 mm	Welding fume extraction nozzle, conical
	094-013967-00000	4,0MMX1,0MM	O-ring for Euro torch connector

10.5 MT- / PM 401G (ON SRA-Kit PM / MT 401G)




Figure 10-5

Item	Order number	Type	Designation
1	094-014177-00001	GN TR 23 63mm Ø 15mm	Gas nozzle
1	094-014178-00001	GN TR 23 66mm Ø 15mm	Gas nozzle
1	094-014179-00001	GN TR 23 63mm Ø 17mm	Gas nozzle
1	094-014180-00001	GN TR 23 66mm Ø 17mm	Gas nozzle
1	094-014181-00001	GN TR 23 63mm Ø 19mm	Gas nozzle
1	094-014182-00001	GN TR 23 66mm Ø 19mm	Gas nozzle
1.1	094-019702-00000	GN NG TR23X4 63mm Ø 13mm	Highly conical gas nozzle, narrow gap welding
1.1	094-022227-00000	GN NG TR23X4 66mm Ø 13mm	Highly conical gas nozzle, narrow gap welding
1.4	094-019626-00000	GN NG M12 73mm	Gas nozzle, narrow gap welding
1.4	094-022226-00000	GN NG M12 76mm	Gas nozzle, narrow gap welding
1.5	094-019624-00000	GNC TR23x4	Gas nozzle body
2	094-013528-00001	CT CuCrZr M9 x 35mm Ø 0.8mm	Contact tip
2	094-013529-00001	CT CuCrZr M9 x 35mm Ø 0.9mm	Contact tip
2	094-013530-00001	CT CuCrZr M9 x 35mm Ø 1.0mm	Contact tip
2	094-013531-00001	CT CuCrZr M9 x 35mm Ø 1.2mm	Contact tip
2	094-013532-00001	CT CuCrZr M9 x 35mm Ø 1.4mm	Contact tip
2	094-013533-00001	CT CuCrZr M9 x 35mm Ø 1.6mm	Contact tip
2	094-013534-00001	CT CuCrZr M9 x 35mm Ø 2.0mm	Contact tip
2	094-013543-00001	CTAL E-Cu M9 x 35mm Ø 0.8mm	Contact tip, aluminium welding
2	094-013544-00001	CTAL E-Cu M9 x 35mm Ø 0.9mm	Contact tip, aluminium welding
2	094-013545-00001	CTAL E-Cu M9 x 35mm Ø 1.0mm	Contact tip, aluminium welding
2	094-013546-00001	CTAL E-Cu M9 x 35mm Ø 1.2mm	Contact tip, aluminium welding
2	094-013547-00001	CTAL E-Cu M9 x 35mm Ø 1.4mm	Contact tip, aluminium welding
2	094-013548-00001	CTAL E-Cu M9 x 35mm Ø 1.6mm	Contact tip, aluminium welding
2	094-013549-00001	CTAL E-Cu M9 x 35mm Ø 2.0mm	Contact tip, aluminium welding
2	094-014024-00000	CT CuCrZr M8 x 30mm Ø 0.8mm	Contact tip
2	094-013129-00000	CT CuCrZr M8 x 30mm Ø 0.9mm	Contact tip

Replaceable parts

MT- / PM 401G (ON SRA-Kit PM / MT 401G)



Item	Order number	Type	Designation
2	094-014222-00000	CT CuCrZr M8 x 30mm Ø 1.0mm	Contact tip
2	094-013113-00000	CT CuCrZr M8 x 30mm Ø 1.2mm	Contact tip
2	094-014191-00000	CT CuCrZr M8 x 30mm Ø 1.4mm	Contact tip
2	094-014192-00000	CT CuCrZr M8 x 30mm Ø 1.6mm	Contact tip
2	094-014193-00000	CT CuCrZr M8 x 30mm Ø 2.0mm	Contact tip
2	094-016109-00000	CT E-Cu M8 x 30mm Ø 0.8mm	Contact tip
2	094-016110-00000	CT E-Cu M8 x 30mm Ø 0.9mm	Contact tip
2	094-016111-00000	CT E-Cu M8 x 30mm Ø 1.0mm	Contact tip
2	094-007238-00000	CT E-Cu M8 x 30mm Ø 1.2mm	Contact tip
2	094-016112-00000	CT E-Cu M8 x 30mm Ø 1.4mm	Contact tip
2	094-016113-00000	CT E-Cu M8 x 30mm Ø 1.6mm	Contact tip
2	094-016114-00000	CT E-Cu M8 x 30mm Ø 1.0mm	Contact tip
2	094-016115-00000	CTAL E-Cu M8 x 30mm Ø 0.8mm	Contact tip, aluminium welding
2	094-016116-00000	CTAL E-Cu M8 x 30mm Ø 0.9mm	Contact tip, aluminium welding
2	094-016117-00000	CTAL E-Cu M8 x 30mm Ø 1.0mm	Contact tip, aluminium welding
2	094-016118-00000	CTAL E-Cu M8 x 30mm Ø 1.2mm	Contact tip, aluminium welding
2	094-016119-00000	CTAL E-Cu M8 x 30mm Ø 1.4mm	Contact tip, aluminium welding
2	094-016120-00000	CTAL E-Cu M8 x 30mm Ø 1.6mm	Contact tip, aluminium welding
2	094-016920-00000	CTAL E-Cu M8 x 30mm Ø 2.0mm	Contact tip, aluminium welding
2.1	094-021189-00001	CT CuCrZr M9 x 100mm Ø 0.8mm	Contact tip, narrow gap welding
2.1	094-019616-00000	CT CuCrZr M9 x 100mm Ø 1.0mm	Contact tip, narrow gap welding
2.1	094-019617-00000	CT CuCrZr M9 x 100mm Ø 1.2mm	Contact tip, narrow gap welding
2.1	094-020019-00000	CT CuCrZr M9 x 100mm Ø 1.4mm	Contact tip, narrow gap welding
2.1	094-019618-00000	CT CuCrZr M9 x 100mm Ø 1.6mm	Contact tip, narrow gap welding
2.3	094-017007-00001	CT ZWK CuCrZr M9x35 mm Ø 1,0 mm	Contact tip, forced contact
2.3	094-016159-00001	CT ZWK CuCrZr M9x35 mm Ø 1,2 mm	Contact tip, forced contact
2.4	094-025533-00000	CT ZWK CuCrZr M9x35 mm Ø 1,6 mm	Contact tip, forced contact
3	094-013856-00003	CTH CuCrZr M9 x 35mm	Contact tip holder
3	094-016425-00003	CTH CuCrZr M9 x 38mm	Contact tip holder
3	094-015489-00003	CTH CuCrZr M8 x 35mm	Contact tip holder
3	094-016018-00003	CTH CuCrZr M8 x 37,5mm	Contact tip holder
4	094-013111-00002	GD Ø14,5 mm, L=25 mm, Ø Außen=20,2 mm	Gas diffuser
5	094-019625-00000	IT ES M22X1,5 M12X1	Insulation part
6	094-019627-00000	ZH GDE 15mm Ø 5mm x 10mm	Centring sleeve
8	094-025864-00004	SRAD DN 25 mm, Ø 41 mm, L 50 mm	Welding fume extraction nozzle, conical
-	094-013967-00000	4,0MMX1,0MM	O-ring for Euro torch connector

11 Service documents

11.1 Circuit diagrams

The circuit diagrams are only intended for authorised service personnel!




Figure 11-1

12 Appendix

12.1 Altitude alignment

The higher the altitude, the less vacuum is required at the connection piece Δp_c of the welding torch to achieve the required welding fume flow rate at the welding nozzle. Determine the corresponding factor in the following table:

$$P_{c \text{ user}}(Z) = f \times \Delta p_c$$

Explanation:

$P_{c \text{ user}}(Z)$	Required vacuum connector
f	Factor (determined in the following table)
Δp_c	Vacuum connector > see 8 chapter

Altitude Z in (m)	Factor f
0	1.00
250	0.97
500	0.94
750	0.91
1000	0.89
1250	0.86
1500	0.83
1750	0.81
2000	0.78
2250	0.76
2500	0.74

12.2 Searching for a dealer

Sales & service partners
www.ewm-group.com/en/specialist-dealers



"More than 400 EWM sales partners worldwide"